```
______
RAIN GAUGE
______
.011 inches of rain or 0.03 cm, according to datasheet.
#define PIN_RAINGUAGE 3 // Digital port 3 pwm
float numbuckettip = 0;
float rainAmount = 0.0;
float rainRate = 0.0;
void setup() {
  Serial.begin(9600);
  pinMode(PIN_RAINGUAGE, INPUT);
  digitalWrite(PIN_RAINGUAGE, HIGH);
  attachInterrupt(1, countRainmeter, FALLING);
}
void loop() {
}
// Interrupt handler for raingauge. Called each time the reed
// switch triggers (one tip of bucket).
void countRainmeter() {
static unsigned long lastmillis = 0;
unsigned long m = millis();
if (m - lastmillis < 200){
// ignore interrupt: probably a bounce problem
 }
 else{
  numbuckettip++;
  rainAmount = numbuckettip*0.011*2.54;
  Serial.print("RAIN: ");
 Serial.print( rainAmount, 2);
 Serial.println(" cm");
// Serial.println(m);
 lastmillis = m;
```